

10x10 Tent

- 4 small poles (9' 5")
- 4 extra small poles (6' 10")
- 4 legs
- 4 stakes
- Tote
 - 4 straps
 - 5 fittings: 4 corners, 1 eight-way top piece
- Tent top

20x20 Tent

- 4 long poles (14' 5")
- 4 medium poles (10' 5½")
- 8 short poles (9' 5")
- 8 legs
- 8 stakes
- Tote
 - 8 straps
 - 9 fittings: 4 corners, 4 middles, 1 eight-way top piece
- Tent top bag

20x30 Tent

- 4 long poles (14' 5")
- 6 medium poles (10' 5½")
- 11 short poles (9' 5")
- 10 legs
- 10 stakes
- Tote
 - 10 straps
 - 12 fittings: 4 corners, 6 middles, 2 six-way top pieces
- Tent top bag

20x40 Tent

- 4 long poles (14' 5")
- 8 medium poles (10' 5½")
- 14 short poles (9' 5")
- 12 legs
- 12 stakes
- Tote
 - 12 straps
 - 15 fittings: 4 corners, 8 middles, 2 six-way tops,
1 top-middle piece (marked)
- Tent top bag